

OPERATOR SAFETY WARNINGS



- Never operate without instructions. Read machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.
- Operator must have instructions before operating the machine. Untrained operators can cause injury or death.

SAFETY EQUIPMENT

The Bobcat® machine must be equipped with safety items necessary for each job. Ask your Bobcat dealer for information on the availability and safe use of attachments and accessories.

- **SEAT BELT:** Check belt fasteners and check for damaged webbing or buckle.
- **SEAR BAR:** When up, it must lock loader controls.
- **OPERATOR CAB (ROPS AND FOPS):** It must be on the loader with all fasteners tight.
- **OPERATOR'S HANDBOOK:** Must be in the cab.
- **SAFETY SIGNS (DECALS):** Replace if damaged.
- **SAFETY TREADS:** Replace if damaged.
- **GRAB HANDLES:** Replace if damaged.
- **LIFT ARM SUPPORT:** Replace if damaged.
- **PARKING BRAKE**
- **BOBCAT INTERLOCK CONTROL SYSTEM (BICS)**



This check mark means: "Follow instructions for proper operations." Carefully read the message that follows.



- Always fasten seat belt snugly and use the seat bar.
- Always keep feet on foot pedals or footrests when operating.



- Never use machine without operator cab with ROPS and FOPS approval.
- Fasten your seat belt!



This Safety Alert Symbol means: "Attention! Be Alert! Your Safety is Involved!" Carefully read the message that follows.



- Never exceed Rated Operating Capacity (ROC).
- Always carry bucket or attachment as low as possible.
- Do Not travel or turn with the lift arms up.
- Load, unload, and turn on flat level ground.



- Never leave loader with engine running or with lift arms up.
- To park: engage parking brake, put attachment flat on the ground, and stop the engine.



- Never carry riders.
- Keep bystanders away from work area.



- Never modify equipment.
- Use only attachments approved by Bobcat Company for this machine model.



- Do Not use machine in atmosphere with explosive dust, explosive gas, or where exhaust can contact flammable material.



- Never use loader as a personnel lift or work platform.